

### **READYHOME ALARM SYSTEM TESTING PROCEDURES**

THE PURPOSE OF TESTING THE ALARM SYSTEM IS TO ENSURE PROPER LOCAL OPERATION AND PROPER COMMUNICATION TO THE CENTRAL STATION.

THE FOLLOWING PROCEDURE SHOULD BE DONE AT **LEAST** ONCE PER MONTH.

1. CALL THE SECURITY MONITORING STATION AT **1-800-868-0063** TO PLACE YOUR ACCOUNT ON TEST. YOU WILL NEED YOUR ACCOUNT NUMBER AND YOUR PERSONAL **PASS CODE**.
2. ARM YOUR SYSTEM IN THE "STAY" MODE, THIS WILL ALLOW YOU TO TEST YOUR PERIMETER DEVICES – DOORS, WINDOWS, ETC. REMEMBER YOUR ENTRY DOOR HAS A TIME DELAY, IT WILL NOT ACTIVATE THE ALARM UNTIL BOTH THE ENTRY AND EXIT DELAY HAS EXPIRED. AS YOU OPEN EACH DOOR OR WINDOW IT IS NOT NECESSARY TO RE-SET THE SYSTEM EACH TIME.
3. ARM YOUR SYSTEM IN THE "AWAY" MODE. THIS WILL ALLOW YOU TO TEST THE INTERIOR DEVICES. OPEN A ENTRY EXIT DOOR
4. IT YOU HAVE ANY EXTERNAL PANIC DEVICES SUCH AS A WIRELESS KEY THEY CAN BE TESTED AT THIS TIME.
5. AFTER ALL TESTING IS COMPLETE; INSURE YOU RE-SET YOUR ALARM SYSTEM BY PUTTING IN YOUR CODE & PRESSING OFF OR USING YOUR OFF BUTTON ON YOUR WIRELESS KEY.
6. CALL THE SECURITY MONITORING STATION, ASK IF THEY HAVE RECEIVED ALL OF YOUR TEST ALARMS. IF THERE IS **ANY QUESTION, RE-TEST THE AFFECTED PART OF THE SYSTEM AGAIN.**
7. IF YOU HAVE ANY QUESTION, PLEASE CALL OUR BUSINESS OFFICE AT **327-7233**.